

# YT Side screen Storage

So just how do you properly stow the sidescreens in a Y/T? Well, read on.



1. Start with the Right Front side screen, fold the flap under the clear, inside facing up.



2. Place the Left Rear side screen on top with the inside down, legs adjacent, so frame to frame with the Right Front Frame.



3. Place the Left Rear side screen on top with the inside down, legs adjacent, so frame to frame with the Right Front Frame.



4. Place the Left Front side screen on top, frame down, flap on top. Again another cut to size towel can reduce scratches.

Note that all the side screens have their legs facing towards you – when in the stowage box they need to “stand” on their legs!



5. Slide the stack of side screens into a towel bag just made big enough to hold the stack in position.



6. Fold over the end flap on the towel bag. For extra ease, you could add a rope handle to the top edge of the towel bag.



7. The side screens bag can now be placed in the stowage box behind the rear seat with the legs at the bottom. It is easier to do when the hood is down.



8. You can now fold the hood as per the workshop manual and tuck it down over & beside the towel bag to stop any “rattling”.



9. You should now be able to fit the stowage cover over the side screens and hood and drive away a happy Y-Typer – don't forget to apply your Sunscreen & Hat!